

Author ID / Author Name – Using ODMS Software

To add or change an author ID/Name on a DVR open the ODMS Dictation Module software and have your Olympus recorder attached to your computer.

Option 1: Click on: Tools > Options > Workflow > Author > Add Name > OK

Option Settings			-		L
Folder Design Workflow User	Settings	E-mail / FTP	Device	Update	
Workflow !Ξ General !Ξ Download ># Advanced Download !Ξ Import	Author Regi autho	List ster Author list in th ors can be register	e software and to u ed.	pload to device for m	nulti-user support. Maximum of 10
Author Worktype Direct Recording Hands Free Recording		Author ID	Priorit	y Level	Modify
Voice Recognition	Author Property Remove				
General	Author I Priority	D: SA Level: 7		Cancel	Up Down

Option 2: Click on Tools > Options > Device > Author List > Set as Default

Option Settings			
Folder Design Workflow	User Settings E-mai	il / FTP Device	Update
Voice Recorder	🚽 🐉 Load 📌 Upd	ate 🖌 🍌 Reset 🕶 🛛 🚚 Set Jol	o Number
DS-7000	Author List		
E - Stand Alone	Register up to	Priority Level	and set a default author.
	SALLY(Det	faultvalue) 7	Only Author IDs registered in the Workflow, Author List, will be available for selection.
Device Security Device Security Author List Worktype List Device Folders Recording		Set as Defaul	Author of Workflow
🗊 Programmable But	ttons		